

## Three-phase Digital Energy meters - BASIC Connection through CT .../5 A till 10.000/5 A

IIST066-01 Stand 13-03-2012



with additional partial active energy counter resettable and inbuilt communication Modbus RTU - 2 tariff

Code	Description
AD3-5CBIC	three-phase digital energy-meter with connection by CT .../5 A, up to 10.000/5 A - 0.05-5 (6) A - 2 tariff and inbuilt communication Modbus RTU
AD3-5MBIC	three-phase digital energy-meter with connection by CT .../5 A, up to 10.000/5 A - 0.05-5 (6) A - 2 tariff and inbuilt communication Modbus RTU - with MID certified


### ⚠ WARNING

The Autometers range of DIN rail mounted meters should only be installed by a competent and qualified electrician who is fully aware of the latest electricity regulations concerning the installation of Electricity meters. The AD3-5 must be installed in a suitable enclosure.

- This family of devices provides a set of energy meters aimed to be connected via external current transformer suitable for every need. All the meters are equipped with an easy to read LCD on which displays all the three phases active energy counters, with a red light LED which blink in proportion to the measured active energy and with a optocoupler that allows the storage of energy on two different tariffs. Depending on the model a insulated Modbus communication interface are built in two solid state relay which generate pulses proportional to the measured energy. Both Modbus communication interfaces offers a set of 59 measures.


Display	Commands
<p>10000 imp/kWh</p> <p>Menu</p> <p>Partial</p> <p>SET</p> <p>Start</p>	<ul style="list-style-type: none"> <li>• Energy value</li> <li>• Energy import (absorbed →)</li> <li>• Energy export (supplied ←)</li> <li>• Energy line (L1-L2-L3)</li> <li>• CT indicator</li> <li>• Tariff Running tariff, called tariff</li> <li>• Energy value "Partial"</li> <li>• Precision control LED</li> </ul> <p>Menu</p> <p>Partial</p> <p>SET</p> <p>Start</p> <ul style="list-style-type: none"> <li>• Menu key for reading selection</li> <li>• Command button for "partial" reading selection</li> <li>• Parameters set</li> </ul>

### Adjusting the Modbus address and Baudrate



- Press the "Menu" key until "Addr 001" appears on the display
  - Press and hold down the "-" key for 4 sec. and release
  - You will notice "001" blinking
  - Press the "+" key to increment the number.
  - To lock the number press and hold down the "Menu" key for 4 seconds. The Modbus address has now been set.
- To alter the Baudrate:** Press the "Menu" key until "br 9600" appears and repeat above steps 2-5.


### Dimension




### MID calibrated

AD3-5MBIC

- Device code and certification data indications
- Safety-sealing between upper and lower housing part



### Sealable terminal covers




### Symbols


- Measuring elements
- Reversal preventing device
- Protected by double insulation

### Cable stripping length and max. terminal screw torque

5 A CT connection main terminals - Screw driver PZ1



Tariff and communication terminals  
Screw driver blade 0.8x3.5 mm



## Main Menu

Device Switch ON

**Page 1:**  
In this page the value of the currently growing 3-phase Active Energy is represented (or the last one that has grown). The energy may be Active Consumed (right row), Active Generated (left row), with Tariff T1 or T2, depending on the current Energy flowing arrow.

**Page 2-3-4:**  
In the second third and fourth pages are represented the remaining 3 energy registers.

**Page 5:**  
In this page the CT ratio appears. The CT ratio is modifiable, see the section CT Ratio.


**Page 6:**  
In this page the Modbus address or primary address appears. This value can be altered, see the section Communication Address

**Page 7:**  
In this page the communication baud rate appears. This value can be altered, see the section Communication Baudrate.

**Page 8:**  
You can read the index of firmware release.


**Page 9:**  
The checksum is periodically calculated to verify that the firmware is reliable. The result of the calculation appears in this page.

**Page 10:**  
All the display segment are visible.



## Partial Counter Menu

In any page of the "Main Menu", a pressure of the "Partial key" allows to enter in the "Partial Menu" where partial active energy counters are readable in the main, second, third and fourth pages (i.e. for monthly energy consumption).. These counters are not saved when the device is switched off. By pushing the partial key in any of the fourth pages, you go back to the "Main Menu".




A pressure of 4 sec. of the "Menu key", in every page of the "Partial Counters" allows to enter in the zeroing menu of the "Partial Counters", and on the display appears "rESEt". The key must be released. To do the reset press it again for 4 seconds. After 4 sec. from the button release if the "Command Reset" is not done, it will go back to the default visualization without the reset.



## Secondary Winding Register Menu

On MID calibrated meters it's possible to show on display all energy registers measured at CT output (also via internal communication interface). For this, in any page of the "Main Menu", the "Menu key" must be pushed for 20 second. In this mode "☉" appears and the meter show the same page of the "Main Menu" but in the first, second, third and fourth pages are shown the energy measured at the secondary winding of the CT. After a minute of "Menu key" inactivity, the meter shows and communicates again the CT input energies.




## Energy Reset

A pressure of 20 sec. of the "Menu key", on every page of the main menu, allows to enter in the zeroing menu of the main registers, and on the display appears "rESET". The key must be released. To do the reset press it again for 4 sec., afterwards it will go back to the default visualization with all registers reset.

After 4 sec. from the button release if the "Command Reset" is not done, it will go back to the default visualization without the reset.


**This feature is present only in the models without MID-certification.**



## Primary CT Current Setting

For the MID certified meters in the CT Ratio page by kept pushed for 4 sec. the "Start (-) key" the value of the primary winding blink on the display. Push "Start (-) key" or "(+)" to change the value. Push the "Menu key" for 4 sec. to confirm, otherwise within 5 seconds the modification will be lost.

**Main Menu:**



For the not MID certified meters to confirm the CT ratio you must reset the energy counters.

**Main Menu:**




## Communication Address

In the Address page by kept pushed for 4 sec. the "Start (-) key" the value of the Address blink on the display:

Push "Start (-) key" or "(+)" to change the value. Push the "Menu key" for 4 sec. to confirm, otherwise within 5 seconds the modification will be lost.

**Main Menu:**




## Communication Baudrate

In the Baudrate page by kept pushed for 4 sec. the "Start (-) key" the value of the Baud rate blink on the display.

Push "Start (-) key" or "(+)" to change the value. Push the "Menu key" for 4 sec. to confirm, otherwise within 5 seconds the modification will be lost.


**Main Menu:**



## Diagnostic Message


### Missing Phases

In case one or more phases is not detected, the corresponding icon disappears from the bottom row of the display. E.g. L2 is not detected.





### Phase Sequence Error

When the 3 phases are not in the correct zero-crossing sequence this message appears and the icon L1 and L2 blink. To make this message to disappears, without change the wiring (Warning, in this way the measure may be wrong) you can keep pushed the "Menu key" for at least 4 sec.



### Error Condition


When the display show these messages, the meters has got a malfunction and must be replaced.



## Service and Maintenance

It should not be necessary to recalibrate device during its lifetime as it is an electronic meter with no moving parts with electronics and voltage and current sensors that do not naturally degrade or change with time under specified environmental conditions. If a degradation in the performance is observed the device has probably been partly damaged and should be sent for repair or exchanged. If the meter is dirty and needs to be cleaned, use lightly moistened tissue with a water based mild detergent. Make sure no liquid goes into the meter as this could damage the meter.


## Wiring diagram



Modbus

Terminals 6 & 7  
(230 V) are only used  
if you require 2 tariffs.  
An external time  
switch will be required.


AD3-5CBIC  
AD3-5MBIC



Modbus

Terminals 6 & 7  
(230 V) are only used  
if you require 2 tariffs.  
An external time  
switch will be required.


AD3-5CBIC  
AD3-5MBIC




Modbus

Terminals 6 & 7  
(230 V) are only used  
if you require 2 tariffs.  
An external time  
switch will be required.


AD3-5CBIC  
AD3-5MBIC



230/400 VAC



230/400 VAC



230/400 VAC

(N) Neutral wire must be connected the meter

### Instructions for the connection of transformer counters

A fuse of 6 A is recommended for the line protection. Current transformers must not be operated with open terminals since dangerous high voltages might occur which may result in personal injuries and property damage. In addition to this, the transformers are exposed to thermal overload.

## Terminal Description

### Modbus

- 1: Modbus network. Shield
- 2: Modbus network. Data +
- 3: Modbus network. Data -
- 4: Modbus network. For the termination of the network short this terminal with terminal 3.
- 6-7: Tariff signal, isolated by a Opto Coupler.  
When there is a voltage of 230 VAC connected the device store energies on the Tariff 2 registers, otherwise on the Tariff 1 registers.

- L1: Voltage connection of phase 1.
- L2: Voltage connection of phase 2.
- L3: Voltage connection of phase 3
- N: Neutral connection.
- K1-I1: Connection of the CT of phase 1
- K2-I2: Connection of the CT of phase 2
- K3-I3: Connection of the CT of phase 3

## Technical Data

Data in compliance with EN 50470-1, EN 50470-3

**AD3-5CBIC / AD3-5MBIC**  
**CT connection till 10.000/5 A inbuilt communication**  
**Modbus**

### General characteristics

• Housing	DIN 43880	DIN	4 modules
• Mounting	EN 60715	35 mm	DIN rail
• Depth		mm	70

### Operating features

• Connectivity	to three-phase network	n° wires	4
• Storage of energy values and configuration	digital display (EEPROM)	-	yes
• Display tariffs identifier	for active energy	n° 2	T1 and T2

### Supply

• Certified voltage range <i>Un</i>		VAC	230 ±20%
• Operating voltage range		VAC	110 ... 276 / 190 ... 480
• Certified frequency <i>fn</i>		Hz	50 ±2%
• Operating frequency range		Hz	48 ... 62
• Rated power dissipation (max.) <i>Pv</i>		VA (W)	≤8 (0.6)

### Overload capability

• Voltage <i>Un</i>	continuous; phase/phase	VAC	480
	1 second: phase/phase	VAC	800
	continuous; phase/N	VAC	276
	1 second: phase/N	VAC	300
• Current <i>I<sub>max</sub></i>	continuous	A	6
	momentary (0,5 s)	A	120

### Display (readouts)

• Connection errors and phase out	discernible from phase-sequence indic.	-	PHASE Err
• Display type	LCD	n° digits	9 (2 decimals)
	digit dimensions	mm x mm	6.00 x 3
• Active energy: 1 display, 9 digit - 2 tariffs + display import or export (arrow)	min. measuring energy	kWh	0.01
	max. measuring overflow	kWh	9999999.99
• Instantaneous tariff measurement	1 display, 1-digit	-	T1 or T2
• Transformer primary current		A	5 ... 10.000
• Display period refresh		s	1

### Measuring accuracy

• Active energy and power	acc.to EN 50470-3	class	B
---------------------------	-------------------	-------	---

### Measuring input

• Type of connection		-	transformer .../5 A
• Voltage <i>Un</i>	phase/phase	VAC	400
	phase/N	VAC	230
• Operating range voltage	phase/phase	VAC	190 ... 480
	phase/N	VAC	110 ... 276
• Current <i>In</i>		A	5
• Current <i>I<sub>min</sub></i>		A	0.05
• Operating range current ( <i>I<sub>st</sub> ... I<sub>max</sub></i> )	transformer connection (CT)	A	0.003 ... 6
• Transformer current	primary current of the transformer	A	5 ... 10.000
	smallest input step adjus. in 5 A steps	A	5
• Certified frequency		Hz	50 ±2%
• Operating frequency		Hz	48 ... 62
• Input waveform		-	AC
• Starting current for energy measurement ( <i>I<sub>st</sub></i> )		mA	3

### Optical interfaces

• Front side ( <i>accuracy control</i> )	LED	imp/kWh	10.000
--	-----	---------	--------

### Safety acc. to EN 50470-1

• Indoor meter		-	yes
• Degree of pollution		-	2
• Operational voltage		V	300
• AC voltage test (EN 50470-3, 7.2)		kV	4
• Impulse voltage test		1.2/50 µs-kV	6
• Protection class (EN 50470)		class	II
• Housing material flame resistance	UL 94	class	V0
• Safety-sealing between upper and lower housing part ( <b>mod. AD3-5MBIC</b> )		-	yes

### Embedded communication

• Modbus RTU baudrate	RS-485 - 3 wires	-	up to 38.400 bps
-----------------------	------------------	---	------------------

### Connection terminals

• Type cage main current paths	screw head Z +/-	POZIDRIV	PZ1
• Type cage pulse output	blade for slotted screw	mm	0.8 x 3.5
• Terminal capacity main current paths	solid wire min. (max.)	mm <sup>2</sup>	1 (4)
	stranded wire with sleeve min. (max.)	mm <sup>2</sup>	1 (4)
	solid wire min. (max.)	mm <sup>2</sup>	1 (4)
	stranded wire with sleeve min. (max.)	mm <sup>2</sup>	1 (4)
• Terminal capacity pulse output			

### Environmental conditions

• Mechanical environment		-	M1
• Electromagnetic environment		-	E2
• Operating temperature		°C	-25 ... +55
• Limit temperature of transportation and storage		°C	-25 ... +70
• Relative humidity (not condensation)		%	≤80
• Vibrations	50 Hz sinusoidal vibration amplitude	mm	±0.075
• Degree protection	housing when mounted in front (term.)	-	IP51(*)/IP20

(\*) For the installation in a cabinet at least with IP51 protection.

# Note

---

---

---

---

---

---

---

---

---

A large grid of graph paper, consisting of 20 columns and 30 rows of small squares, suitable for calculations or drawing.